

5" BAR FEED - PNEU. EQUIP.

Speed control	B-93689
Breather vent	B-95755
Muffler	B-105720
Air cyl.	A-104120
3-way, 2 pos., cam operated	B-104122
3/8 NPT, CW1337	
Regulator 3-50 PSI	B-104123
R-10-02-L00	
Gage, 1/4 NPT, 0-60 PSI	B-104124
RRP-49-076	
Bracket GRP-11-006	B-104125
Purge valve 1/8 NPT S-4P-2M	B-104126
Flow control valve 2" NPT	B-104130
FF1-SHPO-16H	
4-way, hand lever valve	B-105714
1/2 NPT 44HLD4410	
4-way, 2 pos., single sol.	B-105715
3/4 NPT 55SAD4410	
Pressure reg. w/gage	B-105716
1/2-30 PSI, 1/2 NPT 4034	
15 PSI relief valve	B-105867
3/4 NPT 4699K35	
Window site 1 1/4 NPT	B-105868
125 PSI A-2890-6	

Pneumatic Diagram A-106049

Ref. Construction Drawings: L-106224, L-106225, L-106227

P/L No. 10593

5" Cap. BARFEED - BASE, REAR PIVOT & SUPPORT ARM

Base	L-105883	Tank test cover	A-106122
Support arm	A-105884	Drip trough	A-106210
Cylinder cradle	A-106029	Key	B-92113
Middle bracket	A-106050	Stud	B-95019
Top bracket	A-106051	Handle	B-95020
Drip trough bracket	A-88895	Stauff 1 $\frac{1}{4}$ pipe clamp	(2) B-101624
Outlet tube	A-103056	Stop plate	B-103052
Collar gasket	A-103057	Key	(2) B-103122
Housing gasket	A-103058	Parker polypack seal	B-104094
Pivot retainer	A-103069	Timken thrust brg.	B-104095
Pivot shaft	A-103070	Label head retract	B-105709
Pivot housing	A-103071	Label head retract regulator	B-105710
Pivot collar	A-103072	Label piston regulator	B-105711
Shim	A-103088	Label 27 gallon capacity	B-105712
Parker valve mtg. plate	A-105550	Pentad mounts	(6) B-105713
Parker regulator brkt.	A-105769	Jergens 1" x 1" Soc Shoulder	B-106053
Numatics valve mtg. plate	A-106028	Shims	(4) B-106222
Pneu. circuit diagram	A-106049	Korfund vibration mounts	(6) B-106216
Lock arm	A-106054	Spring	C-2075
Cam	A-106055		

Construction Drawings: L-106224 (base), L-106225 (base), L-106226 (rear pivot), L-106227 (support arm)

P/L No. 10590

5" Cap. BARFEED - SLIDING HEAD W/COLLAR

Sliding member	A-103097	Guide rod	(2)	B-105546
Cyl. rod ext.	(2) A-103061	Collar shim	(2)	B-106223
Split bushing	A-105540	Brass brg. seal		A-105981
Front brg. carrier	A-105919	Ball brg. KG075XPO		B-91165
Front brg. retainer	A-105972	*Air cylinder	(2)	A-104120
Front brg. bushing	A-105973	*Speed control	(2)	B-93689
Top tube guard - LH	A-105982	Spring	(2)	B-48061
Bottom tube guard	(2) A-105983			
Cyl. collar - 5"	A-106027			
Collar spacer	A-106125			

*Ref. Listed w/Pneu. Equip.

Construction Drawings: L-106224 (guards), L-106228, L-106229, L-106230 (sectional views)
P/L No. 10616

5" Cap. BARFEED - CYL, PISTON & LIVE CENTER

Follower plate	A-103087	Shim	(4)	B-106222
Cylinder	A-103096	Dbl row bearing	(2)	B-91181
Piston	A-103098	U-Cup seal	(2)	B-104099
End cap	A-103100	Wear ring	(2)	B-104100
Bearing sleeve	A-105918	Piston cup		B-104101
Live center	A-105969	Wear ring		B-105556
Live center insert	A-105970	U-Cup seal		B-105718
Wear ring retainer	A-105971			

Construction Drawings: L-106228, L-106229 (end cap)
P/L No. 10592

5" Cap. BAR FEED - LOADING ARM

Hinged tube w/bushing		L-105650
Extension tube w/bushing		L-105651
Feed roller		A-67440
Side plate	(2)	A-105652
Hinge pin		A-105653
Keeper		B-69998
Extension latch		B-105655
Stop block		B-105656
Latch		B-105657
Roller shaft		B-105658
Shaft		B-105659
Spacer		B-105660
Brz bushing NL2428-16	(2)	B-77349
" " NL1620-6	(2)	B-88673
" " NL1620-8	(2)	B-91894
Detent pin CL-8-DEP-5.5		B-105654
Spring		C-2075

Construction Drawing: L-106231

P/L No. 10617

5" Cap. Bar Feed w/#5 or #7 Cap. ATL - Tooling

Tooling stand	L-106052
Bushing adapter #1	A-105974
" " #2	A-105975
" " #3	A-105976
" " #4	A-105977
" " #5	A-105978
" " #6	A-105979
" " #7	A-105980
Stock pusher #1	A-106030
" " #2	A-106031
" " #3	A-106032
" " #4	A-106033
" " #5	A-106034
" " #6	A-106035
" " #7	A-106036
Inner sleeve #1	A-106128
" " #2	A-106129
" " #3	A-106130
" " #4	A-106131
" " #5	A-106132
" " #6	A-106133
Holder wrench	B-34523
3/8 hex T-wrench	B-106134

Construction Drawing: L-106232

P/L No. 10618